## **Carrot Candy Bag**

## TOP OF CARROT CUT 2 RIGHT SIDE CARROT BODY CUT 2 RIGHT SIDE

2. Layer the carrot/top pieces, right sides together and raw edges lined up. Pin the sides.



1. With right sides together, sew top of carrot (green) to carrot body (orange) with ¼" seam allowance. Make two.



Starting at the second mark with a backstitch, sew around the bottom of carrot and back up finishing at the mark on the opposite side, stop and backstitch. Then sew from the next mark to the top of the carrot top finishing with a backstitch.



5. Press side seam allowances open. Fold the top edge down ¼" to wrong side and press.



6. Fold the carrot top down so the turned-under edge covers the row of stitching and seam allowance. Pin in place.

7. Turn the bag right side out and press. Top stitch carrot top to carrot, <sup>1</sup>/<sub>8</sub>" from edge, catching all seam allowances. Mark the stitch lines for the drawcord casing. Stitch around the carrot top to create the casing.



## DRAWCORDS

Cut 2 drawcords 1" x 19" of green fabric.

Make drawstring: fold the strips in half lengthwise, wrong sides together, and press the fold.

Unfold and turn the raw edges of the strip into the center crease; press.

Fold again, on center crease and press. Topstitch along the edge of the length of drawstring. Make 2 drawstrings: ¼" x 19"



